

---

Subject: Re: Damping of concrete backwall.

Posted by [Kim Schultz](#) on Tue, 18 Jan 2005 14:10:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Adrian.I will build some corner basstraps first, and then place some fibreglass to absorb the first reflections from the speakers.And if needed I will pad the ceiling with fibreglass too at the first reflection.I have found out that the "boong" sound is the room ringing at the room modes, and that is in the bass freq, so the traps should help this.

---