
Subject: Re: Atwater Kent radio restoration
Posted by [Wayne Parham](#) on Mon, 13 Jun 2005 20:02:25 GMT
[View Forum Message](#) <> [Reply to Message](#)

Replace the capacitors with polypropylene capacitors of the same value. They are pretty common, so you can get them from any electronics supplier.
