

---

Subject: Re: Bunch of Cool Stuff

Posted by [Wayne Parham](#) on Thu, 10 Aug 2006 16:07:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yes, it's better to use a load resistor. Tube amps are voltage amps and the output transformer steps down the voltage. So they're sensitive to no-load conditions. But if you don't apply an input signal, there won't be an output signal. It isn't like it will smoke without a load; Just don't crank it unless there's a load.

---