Subject: Re: Sovtek Mig-100, wiring question. Posted by tom on Sun, 13 Apr 2008 18:16:46 GMT View Forum Message <> Reply to Message

You can set up a full stack by using two 4x12 cabs. In my case, i use two orange 4x12's. They each have an impedence of 16 ohms. The two together give an impedence of 8 ohms so you connect the first cab to the 8 ohm input on the head. Then run the second 4 x 12 out of the first 4 x 12 through the second input/output (first cab out of the head - second cab out of the first cab) Your cabs must be wired parallel for this to work. Your guitar tech can do this for you.

Page 1 of 1 ---- Generated from AudioRoundTable.com