
Subject: Re: 3BX III Transistion Level Potentiometer
Posted by [Wayne Parham](#) on Wed, 10 Jan 2007 07:10:40 GMT
[View Forum Message](#) <> [Reply to Message](#)

Many generic potentiometers have a very long shaft, around 2". Most people cut the shaft down to size with a hacksaw. This lets the part be useful for a variety of applications and panel thicknesses.
