

---

Subject: Two alternatives

Posted by [wunhuanglo](#) on Mon, 31 May 2004 14:46:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

1. Buy any screw you want in the hardware store. Stick them into a piece of foam and spray paint them with a quality paint (Rustoleum? Krylon comes in every sort of black imaginable) to color the heads.2. Buy any screw you want in the hardware store. After install, use a "paint pen" from a crafts-type shop (not a permanent marker) to color the heads.

---