

---

Subject: Re: How Thick is Thick Enough?

Posted by [GarMan](#) on Tue, 29 Jun 2004 12:22:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

You should try moving my 2PI Towers, built with 1" MDF all around!!I'm thinking 3/4" with good window bracing is all I need. Good point about the front panel. Once you cut for a flush mount, there's not much left to secure the driver.I was surfing last night and saw some examples of extreme DIY cabinets. One guy built his speaker with three layers of 1/2" MDF. The middle layer was more of a spacer to allow him to fill the core with sand.thanks,Gar.

---