
Subject: Re:Insert flap "A" and throw.....

Posted by [BillEpstein](#) on Sun, 01 Aug 2004 21:37:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

....the Roto-zip away. Hopefully you bought it at the Depot as well. In which case you can return it and the accessories and get a 40 or 50 dollar Ryobi plunge router which will do all you need. If not possible, hold on for dear life and make several passes that are maybe 1/4" of the rabbet at a time. Then make the finish pass and finally, go clockwise, known as a "climb cut" to finish the edges. The Roto and Dremel tools are for making outlet cuts in drywall and thin sheet metal. Also OK for polishing and small grinding. Everything else is wishful thinking.
