

---

Subject: Re: Back to square one, so to speak  
Posted by [Bill Fitzmaurice](#) on Mon, 30 Aug 2004 15:48:36 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I use holesaws with a drill press whenever possible; they are tricky with hand held drills. With a hand held I use a heavy duty 1/2" drill at 800-1000 RPM with the workpiece clamped to the workbench. I did use a 1/2" radius quarter round router bit to chamfer the inner side of the mounting holes to allow me to get in there with a tube of silicone sealeant to seal the drivers to the baffle.

---