
Subject: Re:Smoky the Bear, says".....

Posted by [BillEpstein](#) on Sun, 24 Apr 2005 20:42:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

I've started fires with 3 1/2 HP routers and 3/4" carbide bits turning at 22k. The culprit is the heat that builds up in the compressed wood fibers and transfers to all that getting-denser-by-the-minute dust. For dados use an upshear bit or clear the cut (back up the bit) every few inches. Rabbets should be ok. It's when the dust has nowhere to go trouble starts.
