

---

Subject: Re: Nice cabinet edges - options?

Posted by [BillEpstein](#) on Sun, 29 May 2005 23:41:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Simple is best. Leave the sides 1/8 or 1/4" proud of the front so the baffle is recessed slightly. Edge-glue a piece of thicker stock to the front that becomes proud of both the front and sides, then roundover. Miter all the edges, then cut slots for splines. Drill holes 3/8 in from each edge 4" apart alternating front and sides then pound contrasting wood pegs into them and sand flush.

---