Subject: Re: Nice cabinet edges - options?
Posted by BillEpstein on Sun, 29 May 2005 23:41:19 GMT
View Forum Message <> Reply to Message

Simple is best. Leave the sides 1/8 or 1/4" proud of the front so the baffle is recessed slightly.Edge-glue a piece of thicker stock to the front that becomes proud of both the front and sides, then roundover.Miter all the edges, then cut slots for splines.Drill holes 3/8 in from each edge 4" apart alternating front and sides then pound contrasting wood pegs into them and sand flush.