
Subject: Re: Filler for mitered edges that aren't flush?
Posted by [gfederys](#) on Mon, 23 Oct 2006 15:34:24 GMT
[View Forum Message](#) <> [Reply to Message](#)

I like mixing some fine sawdust from the wood with a 2 part hobby poxy. A drop from each ought to do it. You could even use a hair dryer to get it to flow into the cracks. Mix it so it's pretty thick. 2 things, don't over do it with the hairdryer and "cook" it, sometimes the "fill" will be darker then the wood, test on scrap first to see if it's right for you.
