

---

Subject: amp enclosure

Posted by [blake](#) on Mon, 26 Mar 2007 06:08:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm building an enclosure for an amp I just built and I have a question about recessing the top plate. I used a rabbet bit to cut out a shelf for the top plate to sit on. The problem is that at the corners I have to pull the bit off the wood and it leaves a curve rather than a square end. Should I just chisel out the last little bit of wood or is there another, better looking way of doing it? Thanks for any suggestions. Blake

---