

---

Subject: Re: Here's Guinevere

Posted by [PakProtector](#) on Wed, 29 Dec 2004 21:10:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's an LED. If I didn't have a string of them to look at every time I build another, I would have to go and look it up somewhere else. It is for a 5687 and two would probably be best. The pot for setting the current of the CCS ought to be a 500R or 1k multi-turn unit. Set it for 15 mA per channel. A 9V, some clip leads, and a DMM with current measuring capability is all that is required for that. rig a single series circuit with the DMM, 9V and CCS, and twist the screw until you get the required current. regards, Douglas

---