

---

Subject: Re: also...more L options

Posted by [Damir](#) on Fri, 21 Jan 2005 18:54:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'd do it "right" - use 150mA choke (then - if needed - we can use the full current capacity of the PT) and power resistor (say, 12k/10W) parallel to cap to draw the critical current. What you think?

---