Subject: buss bar
Posted by PakProtector on Fri, 18 Feb 2005 21:36:25 GMT
View Forum Message <> Reply to Message

Hey-Hey!!!,For attachments to the caps, I took something like an inch and a half of 14 ga bare copper and bent it into a 'U' and soldered one to each terminal of the cap. it left a nice pair of wires sticking out to attach stuff to.Further grounding instructions: gather all the signal grounds, like the jacks and cathode and volume pot negative together and lead a single connection to the cap's negative terminal.I forgot that one and chased a bit of noise out of the new one when I rolled the last one over(to take its stepped attenuator volume box out) and discovered the difference.regards,Douglas