
Subject: Re: Too late

Posted by [colinhester](#) on Fri, 04 Mar 2005 21:20:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

I mounted the RS volume pot (271-1732) without insulating washers or any effort to isolate from the chassis. I just assumed the wiper housing was isolated from the leads. Is this not the case? What volume pot did you use and how did you isolate it? I cannot really tell from your pictures, which BTW I have really enjoyed looking at. Very clean layout, kinda makes mine look like a rat's nest.....Colin
