

---

Subject: Millett's amp

Posted by [Manualblock](#) on Sat, 19 Mar 2005 15:58:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Say T; why do you think Pete decided not to use ccs but instead goes with tube regulation? I ask only because you said you worked on the E-Linear thing in tandem. Is the fact that that amp is SE have anything to do with it? Also for the more electronically challenged, how do you do the bias wiring and tie-in the ccs1 to the A- leg? I am going to point out here that as a beginner the Guinevere wiring job had an intuitive feel that could be expressed directly from the schematic; however this is another animal. I look at this schematic and see nothing but questions and few answers pop out at me. What are the catastrophic failure modes possible here and am I seeing this accurately or is this one of those things that look more difficult than they are? Also can we get a BOM on this ? Also; I don't see a commitment to any particular tube, has this been left open or is it cemented in yet? Thanks BTW, J.R.

---