

---

Subject: Wall Drug

Posted by [PakProtector](#) on Sun, 05 Jun 2005 10:34:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

with silicon PN junction diodes, putting them in series gives you a PIV which is the sum of the individual PIV's. SiC is not the same, regards, Dogulashope you got some sleep

---