

---

Subject: Re: PCB's

Posted by [Damir](#) on Tue, 03 Jan 2006 13:37:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi & welcome! I always used "primitive" method - marker, then nail polish for the Cu-traces, and Fe-III-Chloride (small clots + water). After a couple of hours, unnecessary Cu is gone and acetone gets rid of nail-polish. Huh, soldering can be better... Good enough for simple PCBs, see the link for another example...

<http://audioroundtable.com/GroupBuild/messages/1079.html>

---