

---

Subject: Re: vanes here!

Posted by [Bill Epstein](#) on Sat, 23 Sep 2006 16:50:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Find a spoke shave at a flea market. Tune and sharpen it. Cut the flare with a jigsaw or bowsaw and Plane the curve to the line with the spokeshave. Or 3M #77 spray glue 60 grit paper on an 1 1/4" dowel. Shouldn't take much longer than the spokeshave. But it's such a satisfying tool to use. I mostly use my Record convex one to smooth out speaker cut-outs after I've managed to have that freakin' dimple cut-out when the hole jig slips as the cut-out is completed.

Spokeshave

---