

---

Subject: Re: Hey Colin, get out that fancy router and table saw

Posted by [Bill Epstein](#) on Fri, 27 Apr 2007 01:09:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Rout off the corners of the cabinet creating a 1/2" wide rabbet on the front and adjacent side. Glue in a strip of hardwood and leave it 1/4" proud of the substrate + veneer. The proud edge of the hardwood after you veneer looks like you did it on purpose and the shadow line it creates is a nice detail. No seam needed. Your Uncle Bill

---