
Subject: Re: Theater Seven Pi--so far so good!
Posted by [Wayne Parham](#) on Tue, 19 Jun 2001 06:18:16 GMT
[View Forum Message](#) <> [Reply to Message](#)

Good work, Jeff!! use R13 insulation for acoustic damping material and 1/4-20 screws and T-Nuts to mount the drivers.Keep us posted on your progress!