

---

Subject: Yet more 4 Pi questions

Posted by [James W. Johnson](#) on Mon, 30 Jul 2001 14:04:45 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Wayne , yesterday I sat down and started figuring out the flats cut I need to make and began wondering if 3/4" material is going to be enough. I went ahead and wrote out the flats cuts for 1" MDF and 1.5" MDF or Baltic Birch as well. Since am spending \$1100 on the parts I don't want to go the cheap route with these cabinets. This is the most I have ever spent on a speaker and they need to keep me happy for a very long time. What should I do? Also I figured the  $V_b$  to be 3.65cuft before subtracting the drivers and port, so the total must be around 3.4cuft add stuffing and it should bring it to around 3.5cuft with a 6"x3.5"x10" the tuning is right around 34Hz....am I going to have a problem with the driver unloading?

---