Subject: Re: His Eminence is here (extremely long)
Posted by Wayne Parham on Wed, 26 Sep 2001 23:08:39 GMT
View Forum Message <> Reply to Message

1. Take one lead of (16 ohm) R1 and solder one lead of (0.47uF) C1 to it. Now take the other lead of R1 and solder the other lead of C1 to it.2. One lead of this pair of components connects to the (+) tweeter output on the crossover. The other lead of this pair of components connects to a wire that goes to the (+) lead on the tweeter.3. R2 (16 ohms) goes between the (+) and (-) leads on the tweeter crossover. A wire goes between the (-) lead on the crossover and the (-) lead on the tweeter.