

---

Subject: Lpad's provide incorrect damping for the network  
Posted by [Wayne Parham](#) on Sun, 18 Nov 2001 20:12:19 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Don't use a standard 8 ohm L-Pad because damping is wrong for the compensation network. Use the suggested R1 and R2 components instead.

---