

---

Subject: Use 2" fiber-filler

Posted by [Wayne Parham](#) on Sun, 16 Dec 2001 01:21:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm afraid that stuff will be too thin and dense. Use 2-3" thick fiberfill like is in the attic of your home. R11 or R13 is perfect.