
Subject: Re: Question for Wayne

Posted by [mikebake](#) on Sat, 12 Jan 2002 23:42:46 GMT

[View Forum Message](#) <> [Reply to Message](#)

From the Drew Daniels treatise on audioheritage.org" Please, even if you hate handling fiberglass, don't substitute other absorbing materials for it. Fiberglass is unique in its physical properties and substitutes will not work as well. Just get some long heavy rubber gloves to handle the stuff, and shower off with cool or cold water when you're done."

Fun reading
