Posted by Wayne Parham on Mon, 14 Jan 2002 04:05:28 GMT View Forum Message <> Reply to Message

Bracing and filling with expansion foam are esential. There are lots of large panels in this system, and they simply must have adequate bracing or the speakers sound terrible. Some previous threads that discuss proper bracing include "Bracing", "ten Pi injection foam - VERY IMPORTANT" and "Bracing: expansion foam".

Page 1 of 1 ---- Generated from AudioRoundTable.com