

---

Subject: Things and stuff

Posted by [Wayne Parham](#) on Mon, 14 Jan 2002 21:36:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

For acoustic damping material, I like to use R11 insulation which is 2" - 3" thick, uncompressed. It often has a paper vapor barrier that I peel off. There are lots of other materials and products that might work but R11 has always worked well for me. You can put a grille over the port. A mesh or something like that would be just fine so long as it is non-restrictive. For fasteners, I like T-Nuts for mounting heavy drivers or when serviceability is important. Wood screws are fine for about 20 tightening cycles but after that, the wood is stretched enough to tear through.

---