

---

Posted by [Wayne Parham](#) on Tue, 15 Jan 2002 02:19:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

In the PiAlign program, there is a section at the far right of the screen that allows you to enter displacement volumes. There is also a little utility program called "Volume.exe" in the distribution archive that helps you calculate offset volumes. You can approximate the volume of drivers and other parts inside the cabinet using composites of primitives. For a full description of this process, please see the earlier post called "Displacement calculations (or measurements)".

---