

---

Subject: Yes, Adam

Posted by [Wayne Parham](#) on Tue, 22 Jan 2002 19:47:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yes, absolutely. Preload can be applied by mechanical braces instead of filling the dead area with expansion foam. I like the expansion foam because it makes a solid damping mass, but you can also leave that area open as long as you use adequate bracing on the panels to keep them from vibrating.

---