

---

Subject: Re: Wayne, C5 question again...

Posted by [Wayne Parham](#) on Fri, 15 Feb 2002 21:02:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

For C5, 100v should be enough, as long as it's non-polarized. If not, replace it with a pair of 20uF polypropylene caps. They're not too expensive and won't get leaky over time as electrolytics do.