

---

Subject: Re: a question about woofer mounting... Till E... or anyone

Posted by [BillEpstein](#) on Sun, 24 Feb 2002 02:25:22 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I used 15 3/8 for the outer diameter, 13 7/8 the inner. And I have some further thoughts about the subject. I don't like what seems to be the convention for driver mounting with the 8 bolts so close to the edge that t-nuts have a hard time grabbing the workpiece. Next cabinet I build is going to have the woofer and horn glued and bolted to the baffle. I stumbled across some adhesive that is sold with an undermount sink kit at Home Depot. Supposed to be aerospace type stuff. Or epoxy would do. Then I would let in a door through the back panel with a wide rabbet to maximise contact surface, like watertight doors. Apply a gasket material and use bolts in t-nuts. Then have access without disturbing drivers and establishing even higher "Q". This is great fun, isn't it? Enjoy!