

---

Subject: 20Hz High pass filter

Posted by [Wayne Parham](#) on Fri, 05 Apr 2002 06:10:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

To limit VLF, use a steep high-pass filter set at or above fl. It's probably best to use an active filter, because components for a passive (speaker circuit) filter will be large and expensive.