Subject: Re: Thermionic 3 with Altec 811 Posted by Wayne Parham on Tue, 09 Apr 2002 20:08:32 GMT View Forum Message <> Reply to Message

Adjust the values R1, R2 and C1. Resistors R1 and R2 set crossover Q and overall attenuation, so they can be used to adjust the amount of upper midrange and vocal overtones. The value of C1 sets the amount and point where top-octave augmentation comes in, so you can adjust the level of "sparkle" with it.

Page 1 of 1 ---- Generated from AudioRoundTable.com