Subject: Re: Another point to wory about.

Posted by bmar on Sat, 20 Apr 2002 20:17:45 GMT

View Forum Message <> Reply to Message

A few simple ways that you could do it would be to use fineered ply for the sides and have that come up to a 25mm square solid wood for the corners.use fineer ply and glue an edge fineer on all edges before assemblingand finally, just fineer the whole box after you build it from MDF.there are lots of ways. none are better than the other. do what is easy for you and also what you have tools to use.ciao