

---

Subject: Quick answer re construction

Posted by [Wayne Parham](#) on Mon, 22 Apr 2002 17:14:15 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Your cutout dimensions are right. Put the insulation on the back, bottom and side nearest the port. Also span the cross-section with a piece attached to the braces. Don't forget to remove the vapor barrier paper from the insulation.