Subject: Re: Filling screw holes for Veneer (Quick filler)
Posted by newjerseybt on Wed, 24 Apr 2002 01:02:20 GMT
View Forum Message <> Reply to Message

In a pinch you can mix fine saw dust (from belt sander) with Elmersfurniture glue. This will not look pretty and will not stain. I amassuming you will veneer over the screws. Fill over the holes 1/16 of an inch as the mix will shrink when dry. Use a sanding block with 60 grit to level the filler.