
Subject: I think you're...

Posted by [LuxmanLover](#) on Fri, 03 May 2002 20:54:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

sanding too soon with too fine a paper. Also try keeping the surface wet longer but make sure you take off ALL the excess or you will have a big mess to sand off. I've got excellent results with only 3 coats and a one wet sand with 320....smooth as a babes behind (The 20 year old kind ...hehehehehe)....but I sanded to 240 on the bare wood first.Kelly