

---

Subject: It is nearly impossible to "overbrace"

Posted by [Wayne Parham](#) on Fri, 24 May 2002 20:26:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Don't skimp on the bracing. The suggestion of every 18" should be considered a minimum, or rather a maximum span of linear board that should be allowed without being braced. Cut braces to fit snugly but not so tight you need to beat them in. We want to support and preload the panels, but not to bulge them out.