
Subject: Hi Edwin. Few more answers.

Posted by [Wayne Parham](#) on Wed, 12 Jun 2002 20:58:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

The damping material I suggest is R11 or R13 fiberglass insulation. It must be supplied

watts RMS continuous power, and it does not sound strained at all even at that power level. So 65 watts will be just fine. I like using wedge-shaped mini-stands because they aim the forward axis of the speaker towards the listener without raising the speaker enough to start getting floor bounce. Another way around floor bounce is to add subs, which then also increase bass extension and smooth room modes. But if that's not an option, use angled mini-stands if you can. Only in cases where you have to get the speakers up over furniture would I suggest stands, and in that case, the furniture may help mitigate some of the floor bounce notch. Gotta run.....it's summertime!