

---

Subject: Another answer, Edwin

Posted by [Wayne Parham](#) on Fri, 21 Jun 2002 16:52:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I use white glue to fasten the insulation. Just run a few lines of glue the full length of the panel to be covered and about 2" apart.

---