Subject: Re: Proper Guitar Spkr Design
Posted by Paul C. on Sat, 06 Jul 2002 15:50:51 GMT
View Forum Message <> Reply to Message

Morris suggests you remove the Piezos, and use the cheap knockoffs as hole fillers, so you don't port your cab. Just screw them in the tweeter holes, don't hook them up.