
Subject: Re: Proper Guitar Spkr Design
Posted by [Paul C.](#) on Sat, 06 Jul 2002 15:50:51 GMT
[View Forum Message](#) <> [Reply to Message](#)

Morris suggests you remove the Piezos, and use the cheap knockoffs as hole fillers, so you don't port your cab. Just screw them in the tweeter holes, don't hook them up.
