Subject: Re: Wayne or anybody: L-pad values
Posted by Adam on Tue, 16 Jul 2002 11:04:36 GMT
View Forum Message <> Reply to Message

Wayne, I don't need the compensation circuit, only the attenuation. Long story, it's for a temporary network for a car horn. Doesn't need the attenuation because of the flare rate and whatnot.Thanks dude.Adam