

---

Subject: Re: Wayne or anybody: L-pad values  
Posted by [Adam](#) on Tue, 16 Jul 2002 11:04:36 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Wayne, I don't need the compensation circuit, only the attenuation. Long story, it's for a temporary network for a car horn. Doesn't need the attenuation because of the flare rate and whatnot. Thanks dude. Adam

---