
Subject: more questions

Posted by [Anonymous](#) on Wed, 17 Jul 2002 18:40:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

Need tutorial - (read the info, still lost) hehelf I take a 12 inch woofer with these specs.qts .32vas
124 litersfs 37hz94dbWhere exactly do I enter this numbers in pialign?Low mid or high mid
sections? What do I enter for low cut/high cut?What if I want sealed not ported ?After entering the
data, the program will output the best boxdimensions? Will it tell me f3?Confused
