

---

Posted by [Wayne Parham](#) on Sat, 10 Aug 2002 16:55:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Place braces between opposing panels, tying them together and preloading them. There is a picture of some installed braces that are done this way on the post called, "Cabinet bracing and other exciting information".

---